



OVERDRIVE PREAMP

www.trickfishamps.com

Operation Manual

Congratulations on your purchase of the Trickfish Overdrive Preamp. The Overdrive Preamp delivers a pleasing soft clipping overdrive, with a dry blend knob to mix in as little or as much dirt as you desire. Followed by an onboard 3 band EQ with shelving bass and treble controls, this highly adjustable overdrive with smart tone shaping allows you to perfectly tailor your sound. Dial in everything from creamy, touch-sensitive sparkle to full-on saturated filth, and all things in between. Whether you're painting your sound with a creamy, touch-sensitive sparkle or pushing it to the limits with full-on saturated distortion, our Overdrive Preamp pedal adapts to your creative vision.

Using the Overdrive Preamp

Start by plugging a 9VDC adapter into the jack on the top of the Overdrive Preamp. Connect an instrument cable from your instrument into the IN jack and an instrument cable from the OUT jack to your amplifier. Press the ON footswitch to engage the overdrive circiut. The footswitch LED will be on and you may begin adjusting the controls of the overdrive and EQ.



- 1. OUT: 1/4" phone jack output
- 2. DC IN: 9V DC power input, center pin negative
- 3. IN: 1/4" phone jack input
- 4. GAIN: Adjusts the amount of overdrive
- 5. BLEND: Sweeps between wet/dry levels
- 6. OUTPUT: Adjusts the overall output level
- 7. BASS: Boost/cut 13dB centered @ ~80Hz
- 8. MID: Boost/cut 15dB centered @ ~1.5kHz
- 9. TREBLE: Boost/cut 15dB centered @ \sim 4.8kHz
- 10. ON: Footswitch toggles effect on/bypass